# MEDACS

SMART CONFIGURABLE	
SINGLE CHANNEL OR DUAL CHANNEL	
DISPLAY OPTIONS	DEPT Transition From Franklich Providence
GALVANIC ISOLATION	EE15
UNIVERSAL OR FREQUENCY INPUT	
HIGH PACKING DENSITY	ESHENCS 0
EASILY CUSTOMISED VIA TFML	S at ( A a US) milectra ( 3) 3 General te 2004-bit Group Leinness from
UNIQUE 'BUS JUMPER' SYSTEM	******
10 YEAR WARRANTY	

# INTRODUCTION

The MEDACS is a totally new concept in DIN rail signal conditioning and consists of a family of DIN rail modules, each one having a high degree of functionality and configurability via a RS485 MODBUS serial communications interface. They accept all common signals and produce an isolated (4 to 20) mA re-transmission signal, a single changeover trip relay, twin normally open relays or various combinations.

For high density systems, dual channel versions are available or for systems that require more local input, single channel versions with an in-built keypad and digital display are available where functions can be accessed via the front panel keys.

Each unit comes complete with a RS485 serial communications port which enables the devices to be integrated into a complete process control system. Unit wiring is simplified and speeded up by using the integral 'bus jumper' system provided with each unit which removes the need for complicated and expensive back plane wiring.

The functionality is further enhanced by the inclusion of a Transfer Function Module Library (TFML) which enables complex transfer functions to be loaded into the device. These can be PID Control, tank linearisation curves, signal accumulators, maximum and minimum data logging etc. all of which can be downloaded from our website www.status.co.uk Alternatively custom functions can be generated to match your specific application and multiple devices can be grouped together to provide solutions for complex applications requiring more variables.

## TRANSFER FUNCTION MODULE LIBRARY (TFML)

TFML has been designed to offer the user enhanced power and flexibility by providing a mechanism whereby each unit can be customised to perform a particular function.

Common Macros are listed below and are available from our web site. They are simply down-loaded into the MEDACS unit. Here are some of the TFML Macros currently available:

#### **USER LINEARISATION CHARACTERISTICS** Cylindrical tank characteristic

### TRANSFER FUNCTION MODULE LIBRARY PROGRAMS

PID function block for current re-transmission PID function block for relay Rate of change limiter Peak Pick/Hold Valley Pick/Hold (A + B)/2 A - B Sensor Validation Wires to Power and communications to one connector are Bussed to all.









# SPECIFICATIONS @ 20 °C

#### INPUTS

#### UNIVERSAL INPUT OVERVIEW

SENSOR mA RTD TC Volts

Pt100, Ni120 K, J, T, R, S, E, N, L, B ± 0.1, ± 10, ± 1, ± 5, (1 to 5) Slidewire\*

(4 to 20), ± 20, ± 10

RANGE

CURRENT INPUT Base Accuracy Thermal Drift Input Impedance Linearisation

0.05 % FS  $\pm$  0.05 % of reading 0.02 %/ °C 20  $\Omega$  Linear, Square root, Power  $^{3}\!/_{2}$ , Power  $^{5}\!/_{2}$ , Custom

Two isolated and regulated 19 V power supplys are available to power the current loops, and are capable of sourcing 25 mA for each channel.

Zero

Span

### RTD

Sensor Range Linearisation Basic Accuracy Thermal Drift

Excitation Current Lead Resistance Effect Max. Lead Resistance (-200 to 850) °C BS EN 60751/JISC 1604/Custom 0.1 °C  $\pm$  0.0 5% of reading  $\pm$  0.004  $\Omega$ /°C 0.01 %/°C 1 mA 0.002 °C/ $\Omega$ 50  $\Omega$ /leg

## THERMOCOUPLE

ТҮРЕ	RANGE (°C)			
ĸ	-200 to 1370			
J	-200 to 1200			
T	-210 to 400			
R*1	-10 to 1760			
S*1	-10 to 1760			
E	-200 to 1000			
L	-100 to 600			
Ν	-180 to 1300			
B*2	-10 to 1650			
Custom	-1999 to 9999			
Accuracy	± 0.04 % FS ± 0.04 % reading or			
	$\pm 0.5$ °C, whichever is greater			
Linearisation	BS 4937/IEC 584-3/Custom			
Cold Junction Error	± 0.5 °C			
Cold Junction Tracking	0.05 °C/°C			
Cold Junction Range	(-20 to 70) °C			
Thermal Drift Zero	4 μ/ °C			
Span	0.02 % /°C			
*NOTES:				
1 Accuracy true for (800 to	1760) °C			
2 Accuracy true for (400 to	1650) °C			
VOLTAGE INPUT				
Range	± 100 mV, ± 1 V, ± 5 V, ± 10 V,			
	(1 to 5) V			
Accuracy	0.04 % FS ± 0.04 % of reading			
Thermal drift	0.02 %/°C			
Input impedance	1 MΩ			
Linearisation	Linear, Square root, Power $3/2$ ,			
	Power $\frac{5}{2}$ , Custom			
*Slidewire	3 wire Potentiometer inputs			
	can be accommodated between			
	50 Ω & 10 ΚΩ			

#### FREQUENCY INPUTS

A wide range of input types and frequencies can be accommodated without the need for Switches or Jumpers. Totalise functions are a standard feature on the single channel version and are stored during power down.

Input Types Namur, low Voltage (> 10 mV), TTL, Open Collector, PFC Frequency range 0.1 Hz to 20 kHz. Accuracy 0.003 % FS

#### DIGITAL INPUTS

Single channel units can also accept two external digital inputs which can be TTL, Open Collector, 24V DC Logic or Potential Free Contacts. Dig 1 is dedicated to a reset/clear function enabled by the configuration software whilst Dig 2 is reserved for use with TFML. Both digitals can be read via the communications and used to signal events.

#### OUTPUTS

Two output option types are available per channel, relay or current re-transmission. The configuration of these will vary depending upon whether they are fitted on the single or dual channel transmitter.





## CURRENT RE-TRANSMISSION OUTPUTS **Output Range**

Single Channel Dual Channel

Maximum Current Output Accuracy

(0 to 10) mA, (0 to 20) mA, (4 to 20) mA source or sink (4 to 20) mA sink < 23 mA 0.07 % or 5 mA, whichever is greater 30 V (in Sink mode) 5 μA/°C

\*Note: Maximum source load 750 R

### **RELAY OUTPUTS**

Max. Power Supply

**Temperature Stability** 

Two relay options are available, either a single changeover or twin independent relays with Normally closed contacts.\*1

Alarm Action	Off, High, Low, Devi	Deviation, Test	
Hysteresis	Programmable (0 to	100) %	
Delay Time* <sup>2</sup>	Programmable		
Start-up Delay	Programmable		
	AC	DC	
Max. Switching Voltage	48 V RMS	48V	
Max. Current	1 A @ 48 V	1 A @ 30 V	
Max. Power	60 VA	30 W	
Contact Resistance	< 100 MΩ		

< 5 ms

100 000 operations

10 000 000 operations

**Operate Time** Electrical Life @ Full Load Mechanical Life

\*NOTES:

- Contacts are Normally Closed i.e the contact is closed at 1 power off and when operating in an alarm condition. The contact opens in the absence of an alarm condition. The active function can be reversed in software.
- 2 Alarm must be continuously present for this period in order to be recognised

#### GENERAL

Response Time Filter Power Requirements Breakdwon Isolation Ambient Operating Range Ambient Storage Ambient Humidity **EMC** Emissions EMC Immunity **Display Range** 

#### 300 ms Programmable or Adaptive 24 VDC + 10 % @ 200 mA 1 kV I/P~O/P~PSU (-30 to 60) °C (-50 to 85) °C (10 to 90) % RH BS EN61326 BS EN61326 -1999 to 9999

#### SERIAL COMMUNICATIONS

Each MEDACS 2000 module comes supplied with RS485 serial communications using MODBUS rtu protocol as standard.

Baud Rate	19.2 kB, 9.6 kB or 1.2 kB
Mode	2 wire or 4 wire available
Device Address	Network unique address 1 to 255

(\*NOTE: that maximum device no. for Modbus is 247)

#### MODBUS

Modbus is a Master-Slave based communications protocol. This means that all messages are initiated by the Master device. In general the Master will communicate with one Slave device at a time, although it is possible under certain circumstances for the Master to broadcast to the entire network. The MEDACS units are Slave devices.

The RS485 mode determines the way that the network is connected together. The 2-wire arrangement, shown above, has both transmit and receive signals sharing the same wires. Although this makes most efficient use of the connections and makes wiring simpler, correct operation depends upon critical timing within the Master device.

#### **DEVICE ADDRESSES**

Each Slave unit requires a unique address. If two units have the same address on the network, both will respond when this address is accessed by the Master and a data corruption will result. Modbus defines a maximum address number of 247, but the electrical characteristics of RS485 limit the number of devices on a network to 32; however, buffering the network increases this number.





OPC

Managed by the OPC Foundation, OPC (Object linking and embedding for Process Control) is an industry standard created with the collaboration of a number of leading worldwide automation and hardware/software suppliers working in co-operation with Microsoft.

The goal of the standard is 'Plug-and-Play'. By using the standard OPC client-server model, any OPC-compliant device will quickly, easily and seamlessly connect to another and immediately work without the need for lengthy installation procedures. The user can then concentrate more on the chosen client software package (e.g. DCS, SCADA, HMI, Plant Scheduling) rather than the problems of system integration.

The application of the OPC standard interface makes possible inter-operability between automation/control applications, field systems/devices and business/office applications.

#### HARDWARE PLATFORM

The minimum hardware requirements to run OPC are:

- IBM compatible PC
- P100 processor or higher
- 64 MB RAM
- 200 MB free disk space
- Microsoft windows
- 95 (SR2)/ 98/ NT4/ 2000

#### M-SCADA

To complement the Medacs range of signal conditioners, Status are pleased to offer the M-Scada software package, available in two versions, Lite suitable for up to 50 tags\* and Professional for up to 100. This scada package integrates the MEDACS/I series with the DM3000 series panel indicators and provides a very cost effective way of constructing a powerful control and monitoring system.



TRENDING





fe	al	Display builder for Animated Mimics		
Lite	ion	Historic and real time trending		
Display builder for Animated Mimics Historic and real time trending Current Alarm Status Alarm Banner Historic Alarm Reports				
		System Security		
		Recipe Handling		
		On-line plant maintenance		
		Sequence Control Language (SLANG)		

The system is easily up-gradeable to a fully functional system with virtually unlimited I/O potential that can accept instruments from a wide range of third party manufacturers.

\* A tag is an input, output or derived variable

#### SELF DOCUMENTATION

Thanks to the digital nature of MEDACS transmitters, selfdocumentation (not feasible with earlier analogue transmitters) becomes possible. In addition to the standard configuration data stored within the transmitters, are data related to the instrument itself such as Manufacturer, Part No., Serial No., Software revision No., Date (which can be used to advise when re-calibration is required), and Sensor Serial No. A 32 character message facility enables additional information, such as the name of the engineer who last serviced the instrument, to be recorded within the instrument itself.

By using the appropriate software tools, a complete device history can be maintained automatically thus ensuring cost savings and reduced down-time due to better programmed maintenance.



## MECHANICAL DETAILS

(All dimensions in mm)



## APPLICATIONS

#### TWIN FLOW METER CONTROL

Application: Accurate measurement of flow over a wide flow range can be problematical due to the turndown of the flow meter providing inaccurate measurement at extremes of span. A two channel MEDACS can take the inputs from two correctly sized flow meters, and by using a TFML function can select the most appropriate instrument for the conditions, signalling a valve to divert flow to the selected instrument. A continuous (4 to 20) mA output proportional to flow is maintained by the MEDACS.

#### **TEMPERATURE/ PEAK VALLEY HOLD**

Application: Monitoring of temperature may require only peak, valley or average temperature to be recorded. A MEDACS can combine the inputs from an Infra Red Temperature Monitor and a photocell or proximity switch to take readings from a continuous process, taking readings only when signalled to do so by the switch. A (4 to 20) mA output proportional to temperature and a relay closure can be provided to count readings, if necessary within certain parameters, i.e. only count rejects etc

### BUILDING MANAGEMENT

Application: In this application in an art gallery, 8 MEDACS units take temperature and humidity inputs from each of the separate gallery areas. Two on board relays on each unit are configured to provide outputs to control air handling units as required. To provide overall visibility, a control room mounted PC displays the MEDACS software package, MSCADA ,which provides all relevant information for display and recording.

For more applications, please visit the 'Application Section' at: www.status.co.uk/medacs.html









## MEDACS AVAILABILITY TABLE

Part Number Inpu	Input	9 V Loop Power	Channels	0/P 1	0/P 2	Display	
		Input	Output				. ,
MED2100	U	✓	х	Single	х	x	✓
MED2122	U	✓	х	Single	C/O relay	C/O relay	✓
MED2113	U	✓	✓	Single	Current O/P	Twin N/C	✓
MED2133	U	✓	х	Single	Twin N/C	Twin N/C	✓
MED2200	U	✓	x	Dual	x	x	x
MED2211	U	√2	x	Dual	Current O/P	Current O/P	x
MED2213	U	√2	х	Dual	Current O/P	Twin N/C	x
MED2222	U	√2	х	Dual	C/O relay	C/O relay	x
MED2233	U	√2	х	Dual	Twin N/C	Twin N/C	x
MED2300	F	x	х	Single	Х	x	✓
MED2322	F	x	х	Single	C/O relay	C/O relay	✓
MED2313	F	x	✓	Single	Current O/P	Twin N/C	✓
MED2333	F	x	x	Single	Twin N/C	Twin N/C	✓
MED2400	F	x	х	Dual	х	x	x
MED2411	F	x	х	Dual	Current O/P	Current O/P	х
MED2413	F	x	х	Dual	Current O/P	Twin N/C	х
MED2422	F	x	х	Dual	C/O relay	C/O relay	х
MED2433	F	x	х	Dual	Twin N/C	Twin N/C	x

KEY:

U

F

Twin N/C

=

Universal Temperature and Process

= Frequency

Two independent relays, closed in alarm and at power off

NOTE: Not all possible combinations are available as shown in the table below



Scada package providing full animated display facilities and alarm monitoring with data logging and real time/ historical trending for up to 50 data points working with Status products only. Supplied with Medacs drivers.

M-SCADA - PROFESSIONAL\*2

M -SCADA -LITE\*2

\*2 As M-Scada-Lite for up to 100 points with additional recipe handling, batch data facilities, on line plant maintenance and report generator. Supplied with Medacs drivers

A variety of waterproof, wall mounted enclosures are available for the Medacs units. Please contact the sales office for more information.

\*1 The OPC server can be used with a host of other proprietary OPC compliant Scada packages.

\*2 Both packages can be upgraded to a complete and fully functional Scada system accommodating many thousands of data points and compatible with all major instrumentation manufacturers and suppliers.

Status Instruments Ltd Green Lane Business Park Green Lane, Tewkesbury Gloucestershire, UK GL20 8DE Tel: +44 (0)1684 296818 Fax: +44 (0)1684 293746 Email: sales@status.co.uk Website: www.status.co.uk 52-215-2328-02 Issue 02

